



Handheld C₂H₄ Ethylene Gas Detector LD-LEGD-A10

Labodam Equipment Ltd.

info@labodam.com | www.labodam.com

Handheld C₂H₄ Ethylene Gas Detector LD-LEGD-A10

Overview

Handheld C₂H₄ Ethylene Gas Detector LEGD-A10 is a portable device with built-in sampling pump having a flow rate of 1 L/min. It meets IP-66 standards which makes it suitable for use in harsh environmental conditions. Rapid speed of sampling, high flow rate, least detection time, compact design, plastic housing, storage space, etc. are some of the features which ensures accurate results in few minutes. It is used in chemical industry, food industry, etc.

Features:

- Highly precise sensors for accurate detection
- Water-proof, dust-proof, explosion-proof
- Response in less than 30s
- Options for units between ppm and mg/m³
- Automatic calibration mode
- Restore factory setting option
- Audio, visual alarm system
- Threshold values for alarm can be set
- 100000 sets can be stored and also re-viewed
- Data transfer through USB (optional)
- Long working hours and rechargeable battery
- Dense plastic housing
- Compact size and easy to use
- Aluminium case to carry the device

Applications:

It is used to detect ethylene gas. Extensively used in brewing and fermentation industry, cold storage places, agricultural research, chemical labs, paper making industry, bio-pharmaceutical plant etc.

Specifications:

Gas	Ethylene C ₂ H ₄
Alarm	Sound, light, vibration
Weight	300 g
Display	LCD dot matrix display
Gas Unit	Units are switchable
Humidity	0 to 95 % RH
Sampling	With internal sampling pump, flow rate is up to 1 L/min, ten grades of pumping suction for selection
Precision	3 to 10% F.S.

Dimensions	205×75×32 mm
Resolution	1ppm
Zero Shift	? ± 1%?F.S./year?
Temperature	-20°C to 50°C
Measure Range	0 to 1000 ppm
Recovery Time	? 10 s
Repeatability	? ± 1%
Response Time	? 10 s
Operating Time	100 h (pump off)
Linearity Error	? ± 1%
Degree of Protection	IP-66