



Portable Coolant and Battery Refractometer LD-LCBR-A10

Labodam Equipment Ltd.
info@labodam.com | www.labodam.com

Portable Coolant and Battery Refractometer LD-LCBR-A10

Overview

Portable coolant and battery refractometer LCBR-A10 is a versatile pocket sized optical instrument that provides instant measurement readings. LCD screen displays measurement data in one view. Ideal for measuring freezing point of ethylene glycol or propylene based cooling systems and cleaners. It also determines the strength of electrolyte solution in batteries.

Features:

- Microprocessor controlled
- Digital meter displays easy to read results
- Automatic and zero calibration with distilled or tap water
- Abrasion and corrosion-resistant coating on sapphire prism
- Automatically turns off after 1 minute of non-use

Applications:

Used in laboratories, research institutes, chemical industry, automobile industry etc.

Specifications:

Weight	90 grams
Battery	1.5 V
HS Code	90275000
Dimensions	121 × 58 × 25 mm
Battery measuring range	1.000 sg ~ 1.5 sg
Cleaner measuring range	0 °C to -40 °C
Ethylene Glycol measuring range	0 °C to -50 °C
Propylene Glycol measuring range	0 °C to -50 °C