



Xenon Test Chamber LD-LXC-A20

Labodam Equipment Ltd.

info@labodam.com | www.labodam.com

Xenon Test Chamber LD-LXC-A20

Overview

This is a complete weather testing instrument that support climate aging test, polymer fixing test with respect to light resistance. With the help of ecological stimulation such as rain, humidity, temperature control and light (Xenon arc lamp to stimulate destructive waves for diverse environment) a large spectrum of environmental conditions-based aging of materials can be tested.

Features:

- Micro computer based temperature and humidity controller is used
- Xenon arc lamp is used to simulate full sunlight spectrum
- Equipped with 1 Water Cooled xenon arc lamp with inner quartz and outer borosilicate filter
- User friendly and efficient
- Comprises of ultrasonic humidifier and dehumidification system to ensure accurate and stable humidity test
- Simulate daylight spectrum
- Environment friendly Refrigerant R404A
- Automatic water supply, water purification system, water saving
- Coloured LCD screen display with different test monitoring mode namely, digital, graphics and animation
- Provision to adjust light intensity

Applications:

Used for various industries such as plastics, paints, rubber, automobiles, motorcycles, petrochemicals and textile products etc.

Specifications:

Power Supply	AC 380 V 50 Hz
Average Lamp Life	1600 hours
Water Spray cycle	1 ~ 9999 Hr 59 M, adjustable
Irradiance (W/?)	100 ~ 1200
Irradiation Source	1 piece of 6500 W water-cooled Xenon Lamp with inner quartz and outer borosilicate filter
Overall dimensions	1200 × 1150 × 1480 mm
Internal dimensions	500 × 760 × 500 mm
Black Panel Temperature	BPT 35 ~ 85 ° ± 2 °C
Relative Humidity Range	50 ~ 98 % R.H ± 5 % RH
Specimen Capacity (pcs)	28

Chamber Temperature Range	Ambient ~ 100 ° ± 2 °C
Specimen holder size (mm)	80 × 15
Bandwidth Measurement (nm)	280 ~ 800